

Dip Tape and Frame

Part Number 14940-0

Used to gauge the depth of product in a storage tank, the amount of ullage and detect the presence and quantity of water.

Complies to ISO 4512.

- See detailed specifications
- Available accessories
- Request a quotation
- More products in this subcategory



FEATURES

- 30 metre steel tape
- Brass winding frame
- To EC class II standard of accuracy

METHODS

ISO 4512

INDUSTRIES

Marine

DETAILS OF METHODS

ISO 4512

Petroleum and liquid petroleum products — Equipment for measurement of liquid levels in storage tanks.

ADDITIONAL INFORMATION

A hardened and tempered carbon steel tape 13 mm wide, 30 metres long, and graduated in metres, centimeters and millimetres. The brass frame is fitted with a carrying handle and a folding winding handle which locks into position.

Requires one of,
Torpedo-Shaped Dip Weight - 0.7 Kgs For Light Oils (14420-0)
Torpedo-Shaped Dip Weight - 1.5 Kgs for Heavy Oils (14460-0)

SPECIFICATIONS

CCCN Code: Tariff 90178010

Agence Nord:

ZA Object'ifs Sud - Lot A3
6 Allée Emilie du Châtelet
14123 Ifs
tél : 02.31.34.50.74
fax : 02.31.34.55.17

Agence Sud:

Bât Le Venango. 392 Rue Jean Dausset
AGROPARC - BP11575
84916 Avignon Cédex 9
tél : 04.90.27.17.95 fax : 04.90.27.17.52



Agence Est:

Parc Club des Tanneries
2 Rue de la Faisanderie
67380 Lingolsheim
tél : 03.88.04.01.81
fax : 03.68.93.01.52

www.detalabo.fr
info@detalabo.fr