

## 40-164 – Holiday detector

### Standards

DIN 4681, 28055, DIN 28063, DIN 30670, DIN 55670, DIN EN 10329, DIN EN 14430, DVGW Arbeitsblatt G462/I, DVGW Arbeitsblatt W400-2



*For illustration only*

### Application

Device for non-destructive holiday detection of coatings via high voltage impulse technology

### Features

This tester has been especially developed for testing sensitive coatings like FBE, enamel, epoxy, Halar etc. An intelligent signal analysis makes it possible to test completely coated parts. The menu-driven sensitivity of the instrument guarantees exact test results. The integrated pore counter makes it easier to meet work specifications and standards.

### Technical Data

Test voltage	5-35 kV in 0.1 kV steps
Battery	Pb 6 V, exchangeable
Charger	230 V, 50 Hz

### Accessories

Accessories are available according to your testing requirements (accessories for grounding, batteries and chargers, testing electrodes, insulated extension bars).